



**Tartle**  
KITCHEN

INSTRUCTION  
MANUAL

# SPICE GRINDER SG01



CONFORMS TO  
UL STD.763

Keep these instructions with the appliance.  
You should read this user manual carefully before using the appliance.



# INDEX

---

1. Unboxing and Setup .....	P.4
2. Operating Instructions .....	P.5
• Preparing to Grind .....	P.5
• Using the Timer Function .....	P.6
• Using the Pulse Mode .....	P.6
3. Recommended Grinding Times .....	P.7-15
4. Storing Unused Ingredients .....	P.16
5. Cleaning and Maintenance .....	P.16
6. Safety Regulations .....	P.16
7. Troubleshooting Guide .....	P.17

# Unboxing and Setup

- Carefully remove all packaging materials.
- Ensure all parts are included:
  - Main grinder unit
  - Two stainless steel grinding bowls with lids
  - Power cord
  - User manual



- 
- Place the grinder on a flat, stable surface near a power outlet.
  - Wash the stainless steel bowls and lids with warm soapy water before first use. Dry thoroughly.
-

# OPERATING INSTRUCTIONS


## A. Preparing to Grind



---

1. Choose one of the stainless steel bowls and fill it with ingredients. (Do not exceed the maximum capacity of 3 cups.)


---



---

2. Secure the bowl onto the grinder base by aligning it with the grooves.

---




---

3. Place the lid securely on the bowl to engage the interlock function.


---

## B. Using the timer function



- 1 Plug the grinder into a power source.
- 2 Turn the timer dial to select the grinding time (0-60 seconds in 15-second increments).
- 3 Press the power button to start grinding.
- 4 The grinder will automatically stop once the selected time has elapsed.

## C. Using the Pulse Mode



- 1 For a coarse grind, press and hold the Pulse button in short bursts (3-second pulses) until the desired texture is reached.
- 2 Release the button to stop grinding immediately.

**NOTE:** When processing a large amount of food, it is recommended to use two grinding cups alternately.



Model	Voltage Supply	Power	Capacity	Weight	Package Size
<b>SG01</b>	120V~ 60Hz	750W	3cups (750ml)	9.26/11.9 lbs	16.5X9X11 inch

# RECOMMENDED GRINDING TIMES



## DRIED CHILI PEPPERS

30's



2 CUPS



Run continuously  
for 30 seconds or until  
desired consistency



## BLACK PEPPERS



2 CUPS



Run continuously for 30 seconds or until desired consistency

# STAR ANISE



3 CUPS



Run continuously for 30 seconds or until desired consistency

# CLOVES



3 CUPS



Run continuously for 15 seconds or until desired consistency



# YELLOW MUSTARD SEEDS



2 CUPS



Run continuously for 30 seconds or until desired consistency

# NUTMEG



2 CUPS



Run continuously  
for 30 seconds or until  
desired consistency

# DRIED MUSHROOMS



3 CUPS



Run continuously for 30 seconds  
or until desired consistency



# PEANUTS



2 CUPS



Run continuously  
for 15 seconds or until  
desired consistency



 We recommend using roasted peanuts instead of raw for smoother results and faster processing.



## CINNAMON STICKS (CRUSHED)

---



2 CUPS



Run continuously for 60 seconds or until desired consistency



## TURMERIC

---



2 CUPS



Run continuously  
for 60 seconds or until  
desired consistency

# ALMONDS



2.5 CUPS



Run continuously  
for 15 seconds or until  
desired consistency



# CUMIN



3 CUPS



Run continuously for 30  
seconds or until desired  
consistency



# PISTACHIOS



2.5 CUPS



Run continuously  
for 15 seconds  
or until desired  
consistency





## COFFEE BEANS

---



2.5 CUPS



Run continuously for 15 seconds or until desired consistency



# PESTO SAUCE



2.5 CUPS



- 2 cups basil
- ¼ cup pine nuts
- 1 clove of garlic
- 1 cup Parmesan cheese
- ¾ cup olive oil



Add basil, pine nuts, garlic and cheese and pulse (3-second pulses) 5 times. Add oil and run continuously for 30 seconds, scraping sides and cover as needed.



## Storing Unused Ingredients

---

- If you have leftover ground spices, remove the grinding bowl and snap on the provided lid.
- Store the sealed bowl in a cool, dry place or in the refrigerator for freshness.

## Cleaning and Maintenance

---

- Unplug the grinder before cleaning.
- Remove the grinding bowl and wash with warm, soapy water or place it in the dishwasher.
- Wipe the grinder base with a damp cloth. Do not immerse in water.
- Ensure all parts are completely dry before reassembling.

## Safety Regulations

---

- Always ensure the lid is securely locked before operation to prevent accidental spills.
- Keep the appliance and electrical plug away from water and other liquids.
- Do not touch the plug with wet or damp hands.
- Regularly check the power plug and cord for any damage. If damaged, stop using the appliance and contact customer support.
- Never insert foreign objects into the grinder while it is operating.
- Always unplug the appliance when not in use or before cleaning.
- Do not attempt to modify or tamper with any safety features.
- Overheating Protection: If the motor stops mid-use, allow it to cool before restarting.
- Secure Placement: Always place the grinder on a stable, level surface before use.
- No Continuous Operation: Do not run the grinder for longer than the recommended grinding times to prevent overheating and motor damage.
- Blade Safety: Handle the grinding bowls with care to avoid contact with sharp blades.
- Children and Unauthorized Users: This appliance is not intended for use by children or individuals unfamiliar with its operation.
- Avoid Overloading: Exceeding the recommended ingredient capacity may lead to damage or inefficient grinding.
- Emergency Shutdown: In case of an emergency, immediately unplug the unit from the power outlet.



## Troubleshooting Guide


Issue	Possible Cause	Solution
Grinder won't start	Not plugged into power outlet	Check and plug into a working outlet
Grinder won't start	Lid not properly secured	Ensure the lid is locked in place
Grinding cups hard to install	Misalignment of tabs	Ensure the grinding cup aligns correctly
Inconsistent grinding	Overfilled bowl	Reduce ingredient amount
Motor stops mid-use	Overheating protection engaged	Unplug and allow to cool before retrying

For additional support, contact [hello@tartlekitchen.com](mailto:hello@tartlekitchen.com)



# Turtle

KITCHEN



Amazon chat



[Hello@turtlekitchen.com](mailto>Hello@turtlekitchen.com)